



|                |              |
|----------------|--------------|
| <b>Symbol:</b> | AUX-VOLVO.01 |
|----------------|--------------|

|                        |              |
|------------------------|--------------|
| <b>Product groups:</b> | Aux Adapters |
|------------------------|--------------|

## Product specifications

|                               |             |
|-------------------------------|-------------|
| <b>Type of car connector:</b> | Aux adapter |
|-------------------------------|-------------|

|                                 |     |
|---------------------------------|-----|
| <b>Cable/adapter structure:</b> | RCA |
|---------------------------------|-----|

|                                 |       |
|---------------------------------|-------|
| <b>Application - car brand:</b> | Volvo |
|---------------------------------|-------|

|                                 |                                                                                                                               |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| <b>Application - car model:</b> | Volvo C30 2004->, Volvo S40 2004->, Volvo S60 2010->, Volvo S80 2006->, Volvo V50 2004->, Volvo V70 2007->, Volvo XC70 2008-> |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------|

|                            |                                    |
|----------------------------|------------------------------------|
| <b>Car Audio features:</b> | for OEM radio with AUX button only |
|----------------------------|------------------------------------|

## Additional information

|                      |          |
|----------------------|----------|
| <b>Gross weight:</b> | 0.071 kg |
|----------------------|----------|